



*289 & 427 Fender Badge – The center of the badge was originally fitted 1 5/8" above the side louver and 2 1/8" from the top edge of the 4<sup>th</sup> louver (counting from the front of the vehicle).*



*Cobra Bonnet & Boot Badges – The center of these badges were originally fitted 18 1/2" back from the forward edge of the boot lid and 11 1/2" forward of the front edge of the bonnet. Badges are centered on the boot and bonnet side to side.*